

Comunicazione tecnica n° **11/03**  
*Technical communication n: 11/03*

data/date: **21/06/2011**

Riferimento modello/i: Perla C6  
*Machine/s kind: Perla C6*

Oggetto: Nuova release software per distributore Perla C6  
*Subject: New software release for Perla C6 vending machine*

Con la presente si informa che è disponibile la nuova release software per distributori Perla C6 con i seguenti dati identificativi:

- Set lingue L1: versione V.1.10 checksum 3FCC
- Set lingue L2: versione V.1.10 checksum DA0A

Tale release si differenzia dalla precedente per:

- Aggiunta opzione visualizzazione descrizione errori al comando 59;
- Aggiunta di nuovi modelli/layout: modelli 5,6,e 7;
- La ricetta Latte del modello/layout 1 è stata trasformata in ricetta capp-ciocc Instant con valore di default solo latte;
- Gestione pagamento a gettone per gettoniere in MDB;
- Reset automatico dello stato "riempimento capsule" alla chiusura della porta;
- Sostituzione a display della scritta "Instant" con la scritta "DECA" dalla lingua n°3 in poi, per le preselezioni decaffeinato;
- In presenza dell'allarme 22 (errore scarico capsula) viene bloccato il riposizionamento del motore gruppo infusore;
- Inserimento Allarme 20 per la diagnostica del micro di zero colonna capsule (funzione attiva in presenza di scheda controllo motore cod. 082730 con software v. 2.60).

Distinti Saluti  
Fas International

*Please be informed concerning the issue of new software release for Perla C6 vending machine with the following identification data:*

- *L1 language set: version V.1.10 checksum 3FCC*
- *L2 language set: version V.1.10 checksum DA0A*

*This release is different from the last one for:*

- *Command 59: errors description display option added;*
- *New models/layouts added: models 5,6 and 7;*
- *Modification of Milk receipt in model/layout 1: from Milk to Capp-choc. Instant with Milk as default value;*
- *Payment management with token for change givers in MDB;*
- *"Capsules filling" automatic rest when the vending machine door is closed;*
- *Replacement of display message "Instant" with message "DECA" from language 3 for all Decaffeinated pre-selections;*
- *Stop of coffee unit motor movement in case of error 22 (capsule discharging error);*
- *Added error n. 22 to analyse zero position micro switch faults (function available in the presence of motor control board item code 082730 with software v. 2.60).*

*Best regards*  
*Fas International*